



**CLIP REMOVAL
ASSEMBLY
DISASSEMBLY**

CLIP REMOVAL

CLIP WITH CLIP




CLIP WITH HAMMER



ASSEMBLY

STEP 1:

Place an end panel (A) into the groove along the shorter edge of the pallet (B). Ensure that the grooved edges of the end panel run vertically



ASSEMBLY

STEP 2:

Press Sure-Lok clips into the slots on the end panel and pallet bottom (clips will only fit in one direction).

NOTE: Clip will make a snapping sound when secure in place.



ASSEMBLY

STEP 3:


Place a side (C) panel into the groove along the longer edge of the pallet and into the groove on the vertical edge of the end (A).

STEP 4:

Clip side panel to end panel and then side panel to pallet.

STEP 5:

Proceed and clip the remaining end and side in place. Ensure that all clips are used!



ASSEMBLY

STEP 6:

Set the top panel (D) in place and press the remaining clips into their corresponding slots.




DISASSEMBLY

STEP 1:

Using a clip or claw of hammer, insert tool into the relief area of the clip and pry off.

NOTE: Use palm of free hand to control the clip release!



STEP 2:

Remove panels in the opposite order of assembly then store for later use.

Safety Tip

Make sure hand is placed on top of clip to prevent possible injury